

Piano

Prompt cleaning is always recommended. Ordinary dirt and stains can be removed with mild soap and water. For more persistent stains use a 1:10 Bleach solution.

Piano will resist without serious discoloration, the repeated actions of normal dilutions of non-abrasive chlorine or ammonia-based cleaners.

NOTE: Be sure to rinse the cleaned area with clean water and dry with a lint free cloth.

The information in this cleaning guide refers to performance in specific tests conducted under laboratory conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.