



Moxie

Prompt cleaning is always recommended.

REGULAR CLEANING AND MAINTENANCE

Clean the soiled area with mild soap and water, then rinse with fresh water and wipe dry with a clean cloth.

EXAMPLE

Dirt
Dust
Grime

FOOD STAINS / OILS

Wipe affected area with a soft cloth or soft bristle brush using a non-abrasive cleaner, for example Formula 409 or Fantastik. Rinse with fresh water and wipe dry.

Ketchup	Butter
Chocolate	Salad Dressing
Coffee	Soy Sauce
Tea	Mayonnaise
Soda	Whiskey

DIFFICULT STAINS

Clean the soiled area with 70% solution of Isopropyl Alcohol (Rubbing Alcohol) and water. It is important to rinse the cleaned area with fresh water after applying the alcohol solution.

Mascara	Motor Oil
Lipstick	Soy Sauce
Hairspray	Coffee
Grease	

HEALTHCARE / DISINFECTION

Wipe the affected area with a soft cloth with appropriate pressure. If some stain persists, spray it with a 10% dilution of household bleach and water and wipe. After applying the bleach solution for the appropriate contact time, wipe or rinse with fresh water.

Disinfection: This material will withstand a 10% solution of Household Bleach and water. It is recommended to wipe or rinse the cleaned area with fresh water after applying the bleach solution for the appropriate contact time.

Blood
Urine
Betadine

NOTE: The use of commercial vinyl conditioners and protectants is NOT RECOMMENDED.

The information in this cleaning guide refers to performance in specific tests conducted under laboratory conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.