

Lumina

Lumina features Cleangene technology. Cleangene is a stain inhibiting polymer inherent to the material make-up. Unlike topical treatments it does not wear off. Cleangene enables the use of strong cleaners such as undiluted Isopropyl Alcohol and high concentrations of bleach, and a variety of other industrial cleaners. With Cleangene, virtually any tough stain can be removed.

Prompt cleaning is always recommended. Recommended cleaning steps are listed by type of stain. For best results follow cleaning steps in order.

REGULAR CLEANING AND MAINTENANCE

Clean the soiled area with mild soap and water, then rinse with fresh water and wipe dry with a clean cloth.

EXAMPLE

Dirt
Dust
Grime

FOOD STAINS / OILS

Wipe affected area with a soft cloth or soft bristle brush using a non-abrasive cleaner, for example Formula 409 or Fantastik. Rinse with fresh water and wipe dry.

Ketchup
Chocolate
Coffee
Tea
Juice

HEALTHCARE

Clean the soiled area with a 10% solution of Household Bleach and water. It is important to rinse the cleaned area with fresh water after applying the bleach solution.

Blood
Urine
Betadine
Disinfectant

DIFFICULT STAINS

Clean the soiled area with 70% solution of Isopropyl Alcohol (Rubbing Alcohol) and water. It is important to rinse the cleaned area with fresh water after applying the alcohol solution.

Eye shadow / Mascara
Lipstick
Crayon
Grease
Mustard

NOTE: The use of commercial vinyl conditioners and protectants is NOT RECOMMENDED.

The information in this cleaning guide refers to performance in specific tests conducted under laboratory conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.